








Max. Distance	Access Interface	Connection Type	Communication Modul	Control Panel	Management			Analysis		Alarm Notice		User		Cellular Location	Android & Iphone Applications		
					Remote Visualisation	Control	Programming	Data Logging	Graphic View	Sms	E@mail	Single Access	Multi Access				
2,5 mt.	PC Software	USB	N/A	Trans-AMF Trans-AUTO	●	●	●	-	-	-	-	●	-	-	-		
1000 mt.		RS-485	Trans-485		●	●	●	-	-	-	-	●	-	-	-	-	
		SMS	Trans-Messenger		-	●	●	-	-	●	-	●	-	-	-	-	-
		GPRS	Trans-GPRS		●	●	●	-	-	0 ₁	-	●	-	●	-	-	-
	Embedded WEB browser	Ethernet	Trans-Web_Ethernet	Trans-SYNCR0	●	●	●	●	●	-	●	●	●	-	-		
		GPRS/ Ethernet	Trans-Web_GPRS		●	●	●	●	●	●	●	●	●	●	-	-	-
	Emko Web Management	Ethernet	Trans-Web_Ethernet	Trans-SYNCR0	●	●	-	●	●	-	●	●	●	●	-	●	
		GPRS/ Ethernet	Trans-Web_GPRS		●	●	-	●	●	●	●	●	●	●	-	●	●
		GPRS	Trans-GPRS		●	●	-	●	●	-	●	●	●	●	●	●	●

0₁ : GPRS modem connected to the PC and SIM card with SMS packed is required.